



2" Paragrannular Cant Under Paraseal Where Wall Meets Footing.

Temporary Tape at all Vertical Seams. (Tape Interrupted In Illustration For Clarity)

Paraseal Membrane With Bentonite Side Against Substrate.

Corner Piece of Paraseal With Bentonite Side Against Substrate. Apply Vulkem 2011T, or Paramastic As Necessary.

Typical Outside Corner

No.	Date	Description	By

Project: **TREMCO** 3735 Green Road Beachwood, Ohio 44122 216-292-5000

Backfilled Walls

Drawn by: J. Davis	Scale: Not To Scale	Date: 05/02/01	Drawing/Index No. BFW-10
--------------------	---------------------	----------------	--------------------------