



Temporary Tape at all Vertical Seams. (Tape Interrupted In Illustration For Clarity)

Paraseal Membrane With Bentonite Side Against Substrate.

Typical Inside Corner

Corner Nails Should Be Within 3" of Corner and Staggered.

1" Continuous Vertical Cant of Vulkem 201T, or Paramastic In Corner Under Paraseal.

2" Paragrannular Cant Under Paraseal Where Wall Meets Footing.

No.	Date	Description	By
<p>Project:</p> <p><b>TREMCO</b> 3735 Green Road Beachwood, Ohio 44122 216-292-5000</p>			
<p>Project: <b>Backfilled Walls</b></p>			
Drawn by:	Scale:	Date:	Drawing/Index No.
J. Davis	Not To Scale	05/02/01	BFW-11