



Temporary Termination  
(See BSW-17).

Poured-In-Place Concrete Wall. (See BSW-24 When Wall is Shotcrete)

Paraseal LG With Bentonite Side Facing Installer. Nail Seams Every 24" O.C. and Staple Every 3" O.C. (BSW-28)

Steel Pile.

Concrete Grout (or plywood) at All Lagging Board Gaps Exceeding 1". (Similar to BSW-09)

Lagging Boards.

Tie Back Waterproofing. (See BSW-12 and 13)

Tie-Back.

Plywood, Grout or Increase HDPE Mill Thickness if Lagging Board Gaps Exceed 1". (Similar to BSW-09)

Paraseal LG Starter Strip Extending 6" Above Footing or Mat Slab. Bentonite Side Facing Installer.

Note: When There Is Also Below Floor and/or Below Footing Waterproofing See BSW-23 for Proper Tie-In With Wall Waterproofing. Also See Section C, "Below Slab-On-Grade."

### Paraseal LG Installation Over Wood Lagging With Steel Piles

No.	Date	Description	By
<b>TREMCO</b>			
3735 Green Road Beachwood, Ohio 44122 216-292-5000			
Project: <b>Blindside Walls</b>			
Drawn by:	Scale:	Date:	Drawing Index No.
J. Davis	Not To Scale	05/02/01	BSW-01