



Temporary Termination Omitted From Drawing For Clarity. (BSW-16)

Poured-In-Place Concrete Wall. (See BSW-24) When Wall Is Shotcrete)

Paraseal LG With Bentonite Facing Installer. Vertical Seams Should Not Occur At Interlocking of Sheet Piling. Nail Seams Every 24" o.c. and Box Staple Every 3" o.c. (BSW-28)

When Vertical Seams Occur at Angled Return of Sheet Piling As Shown, Then Open Edge of Seam Should Aim Away From Building.

Note: When There Is Also Below Floor and/or Below Footing Waterproofing, See BSW-23 For Tie-In With Wall Waterproofing. Also See Section C "Below Slab-on-Grade"

All Paraseal LG Seams Lap 4" Min. When Wall Is Shotcrete. (BSW-24)

Paraseal LG Starter Strip Extending 6" Above Footing or Mat Slab. Bentonite Side Facing Installer.

Steel Sheet Piling: Profile May Vary From One Drawn.

Retained Earth

Optional Technique: Sand Fill Behind Plywood.

Optional Technique: 3/4" (Min) Plywood Anchored Every 12" (Max) o.c.

Paraseal LG Installation Over Steel Sheet Piling

No.	Date	Description	By
3735 Green Road Beachwood, Ohio 44122 216-292-5000			
Project: Blindside Walls			
Drawn by:	J. Davis	Scale:	Not To Scale
Date:	06/04/01	Drawing Index No.:	BSW-02