



Note:
When There is Also Below-Floor and/or Below-Footing Waterproofing See BSW-23 For Proper Tie-In With Waterproofing. Also See Section C, "Below Slab-On-Grade"

Paraseal LG Starter Strip Extending 6" Above Footing or Mat Slab. Bentonite Side Facing Installer.

Paraseal LG Installation Over Shotcrete With Concrete Piles.

No.	Date	Description	By
<p>TREMCO 3735 Green Road Beachwood, Ohio 44122 216-292-5000</p>			
<p>Project: Blindside Walls</p>			
Drawn by:	Scale:	Date:	Drawing Index No.
J. Davis	Not To Scale	06/08/01	BSW-04