



Wood Lagging.

Steel Soldier Pile.

Parastick N Dry. Apply Paraprimmer First to All Surfaces.

Paraseal LG With HDPE Side Against Lagging.
Nail Every 24" o.c. and Staple Every 3" o.c. (Typ)

Interrupting Paraseal LG at Vertical Soldier Piles - Plan View.

No.	Date	Description	By
TREMCO 3735 Green Road Beachwood, Ohio 44122 216-292-5000			
Project: Blindside Walls			
Drawn by:	Scale:	Date:	Drawing/Index No.
J. Davis	Not To Scale	06/08/01	BSW-07