



Steel Soldier Pile. (The-Back Omitted Here  
For Clarity - See BSW-12 and 13)

1/4" to 1/2" Plywood (Typical to Bridge  
Any Void or Gap Greater Than 1")

Fill Gap With Grout or Cover With Plywood,  
1" to 2" gap - Use 1/4" Plywood.  
2" to 3" gap - Use 1/2" Plywood.  
or  
Use 40 or 60 Mil. Paraseal With  
4" Seam Overlaps. (Contact Mfg.)

Nail Near Both Edges of Plywood. Every 12" o.c.  
With 4" Seams Overlapping.

Paraseal LG With HDPE Side Against Lagging.  
Wood Lagging. (Lagging Ties Omitted Here  
For Clarity - See BSW-10 and 11)

Installing Paraseal LG Over Lagging Board Gaps - Plan View

No.	Date	Description	By
<p><b>TREMCO</b> 3735 Green Road Beachwood, Ohio 44122 216-292-5000</p>			
<p>Project: <b>Blindside Walls</b></p>			
Drawn by:	Scale:	Date:	Drawing Index No.
J. Davis	Not To Scale	06/11/01	<b>BSW-09</b>