



Paraseal LG With Bentonite Side Facing Installer.

Nail With Washer Every 8" o.c. Around Lagging Tie.

Paramastic or Vulkem 201 T.

Cut Off End of Lagging Tie Before Applying Paramastic or Vulkem 201 T.
(These are NOT Tie-Backs)

Wood Lagging.

Paraseal LG Installation at Lagging Ties

No.	Date	Description	By
TREMCO 3735 Green Road Beachwood, Ohio 44122 216-292-5000			
Project: Blindside Walls			
Drawn by:	Scale:	Date:	Drawing/Index No.
J. Davis	Not To Scale	06/11/01	BSW-10