



Install Primary Paraseal LG Sheet By Cutting Small Holes Into Sheet Which Correspond To Stud Locations and Slip Sheet Over Stud. Nail At 12" o.c. Down Both Sides.

12" Wide Strip of Paraseal LG. Cut Small Holes In Paraseal LG and Slip Over Stud.

Wrap 1" Parastick N Dry Around Studs Tight To Paraseal LG and Pinch Closed.

Studs (or Form Ties).

Paraseal LG Installation at Studs or Form Ties.

No.	Date	Description	By
<b>TREMCO</b> 3735 Green Road Beachwood, Ohio 44122 216-292-5000			
<b>Blindside Walls</b>			
Drawn by: J. Davis	Scale: Not To Scale	Date: 06/11/01	Drawing/Index No. <b>BSW-11</b>