



Paraseal LG Installation at Tie-Back.

First - install Vulkem 201 T filling behind and over Tie-Back - extend on lagging surface 6 inches out in all directions.

Second - install Paraseal LG as close to the Vulkem 201 T as possible. Bentonite side towards installer. Overlap onto the Vulkem is permissible. -Allow Vulkem 201 T to cure overnight.

Third - Apply 60 mil coating of Vulkem 201 T over the cured Vulkem 201 T and extend 2 inches onto the bentonite face of the surrounding Paraseal LG.

Final - install a Paraseal LG cover sheet with HDPE side facing installer.

No.	Date	Description	By

Project: **TREMCO** 3735 Green Road Beachwood, Ohio 44122 216-292-5000

Blindside Walls

Drawn by: J. Davis	Scale: Not To Scale	Date: 06/11/01	Drawing/Index No. BSW-12
--------------------	---------------------	----------------	--------------------------