



First - install Vulkem 201 T filling behind and over Tie-Back - extend on lagging surface 6 inches out in all directions.

Second - apply Paraseal LG with bentonite side towards installer. Overlap onto the Vulkem 201 T minimum 2 inches. Form blockout with sloped roof. Paraseal LG must be exposed minimum 2 inches around inside of blockout. -Allow Vulkem 201 T to cure overnight before pouring concrete or shotcrete. Remove blockout forms and stray concrete.

Third - Apply 60 mil coating of Vulkem 201 T over the cured Vulkem 201 T and extend 2 inches onto the bentonite face of the surrounding Paraseal LG. Apply SUPERSTOP or PARASTOP II around the inside perimeter of the blockout.

Allow Vulkem 201 T to cure overnight.
Fill blockout with structural concrete.

Paraseal LG Installation at Tie-Back - Blockout Method.

No.	Date	Description	By
TREMCO 3735 Green Road Beachwood, Ohio 44122 216-292-5000			
Project: Blindside Walls			
Drawn by:	Scale:	Date:	Drawn/Revised No.
J. Davis	Not To Scale	06/11/01	BSW-13