



Paraseal LG with HDPE Side Against Wood Lagging. Cut a Hole In The Sheet For The Pipe To Pass Through.

Slip A Square "Washer" Of Paraseal LG Over The Pipe And Nail At Corners And Every 4" o.c. HDPE Side Should Be Against Other Sheet and Washer Should Fit Tight Around Pipe. If Washer Cannot Be Slipped Over Pipe, Then Cut A Slit In Washer Before Installation.

Wrap 1" Parastick N Dry Around Pipe Tight Against Paraseal LG Washer and Pinch Closed Where The Ends Meet. Some Pipes May Require Priming With Paraprimer.

Pipe.

6" Min.

1"

Paraseal LG Installation at Wall Penetration.

No.	Date	Description	By
<p><b>TREMCO</b> 3735 Green Road Beachwood, Ohio 44122 216-292-5000</p>			
<p>Project: <b>Blindside Walls</b></p>			
Drawn by:	Scale:	Date:	Drawing Index No.
J. Davis	Not To Scale	06/13/01	BSW-17