



Fold Paraseal LG Back On Itself To Protect Bentonite Side. Then, Untold and Nail To Backfilled Wall Every 24" o.c.

Temporary Tape and 24" o.c. Nailing At All Backfilled Seams.

Paraseal LG with HDPE Side Facing Installer.

Backfilled Wall of Different or Like Material.

PARASTOP II WATERSTOP  
or SUPERSTOP

6" Min.

6" Min.

Paraseal LG Installation at Blindside to Backfilled Transition - Plan View.

No.	Date	Description	By

Project: **TREMCO** 3735 Green Road Beachwood, Ohio 44122 216-292-5000

Blindside Walls

Drawn by: J. Davis	Scale: Not To Scale	Date: 06/15/01	Drawing/Index No. BSW-22
--------------------	---------------------	----------------	--------------------------