



Notes:

When Spraying Shotcrete or Other Materials Against Paraseal Products, Spray Either Directly at Seam or at Closed Edge of Seam So As Not To Lodge Sprayed Material Between Lapped Sheets. Never Spray Into Open Edge of Seam.

When Spraying Shotcrete or Other Materials Use Paraseal LG ONLY.

Seams May Run Horizontal (As Shown) or Vertical. When Running Horizontal The Open Edge of The 4" Seams Should Be Aiming Up.

Nail 4" Seams Every 24" o.c. and Staple Every 3" o.c. (BSW-28)

Proper Installation of Shotcrete Against Paraseal LG.

No.	Date	Description	By
TREMCO 3735 Green Road Beachwood, Ohio 44122 216-292-5000			
Blindside Walls			
Drawn by: J. Davis	Scale: Not To Scale	Date: 06/18/01	Drawing Index No. BSW-24